

DO-ALL OUTDOORS

BULLET BENCH

- After unzipping your Bullet Bench cover, Extend Leg A until straight and depress silver locking pins to lock into place.
- Extend Leg B depressing silver locking pins to secure it into place.
- Once both legs are locked straight, pull legs away from bench leaving the two legs crossed. Pull back securing bolts on Leg B when lined up with receiver holes in leg A. Release bolts and lock legs securely together.
- Set bench upright and flip seat support over to its upright position then slide seat post into receiver on chair support.
- Next screw Gun-V (or gun rest) into receiving hole on table top to desired height. Make sure to leave Wingnut above table so it can be used to secure Gun-V at whatever height you wish.
- The upper portion of the Gun-V can be adjusted in the same way.

